



GapCap, FasciaCap 90 Installation Instructions

Welcome to GapCap! Your solution for enhancing the appearance of your deck by seamlessly covering corner gaps. Here's how to install your GapCap, FasciaCap 90.

Installation Steps:

1. Initial Setup:

- Install the fascia boards on the rim joist and cut the ends “square” and flush with the outside corner of the rim joists. Do not overlap or miter fascia board ends.

2. Measure and Mark:

- Measure the height of the fascia board you have installed. Cut the FasciaCap 90 to match the height of the Fascia, if needed.

3. Installing the GapCap FasciaCap:

- Install the FasciaCap with the cut end up, and align the outside corner with the TopCap 90, or outside corner of the deck boards above.
- Secure the GapCap FasciaCap 90 using typical composite deck screw fasteners. Ensure these are the correct size. For best results, predrill through the FasciaCap 90 holes with an 1/8” bit to ensure proper alignment.
- Use the drill to drive the screws in below the GapCap FasciaCap surface and seat the screw to allow for the plug.
- Install the provided plugs, and orient to match the grain.

Quick Tips:

- Make sure FasciaCap 90 is aligned and plumb with the deck corner.
- Pre-drill for best results.
- Use a small dab of clear silicone in the plug hole for long-term bond of the plug.

By following these detailed steps, you can effectively install a GapCap FasciaCap 90 onto your new or existing deck to cover unwanted gaps and ensure a professional finish.