



GapCap, TopCap 90 Installation Instructions

Welcome to GapCap! Your solution for enhancing the appearance of your deck by seamlessly covering corner gaps. Here's how to install your GapCap, TopCap.

Installation Steps:

1. Measure and Mark:

- Use the speed square to align and identify the exact position where the GapCap TopCap will be installed. Ensure it lines up with the outer corner of the deck.
- Mark the width of the underside of the GapCap, TopCap on the deck framing. Deck boards should be cut exactly 3/16" away from underside of GapCap, TopCap. This allows for expansion and contraction. (Note: If installing on new treated decking, cut the gap tight to the GapCap.)

2. Installing the Deck Boards:

- Install the deck boards in a picture frame style, per the manufacturer's instructions.
- Make sure to leave exactly 3/16" inch space between the deck board miter and the underside of the TopCap.

3. Installing the GapCap TopCap:

- Insert the GapCap, TopCap into the groove, ensuring it aligns perfectly with the corners of the deck boards.
- Secure the GapCap, TopCap using the composite deck fasteners.
- Use the drill to drive the screws in below the GapCap TopCap surface.
- Install the provided plugs, and orient to match the grain.

4. Final Checks:

- Inspect the installation to ensure there is enough room for the deck boards to expand and contract with changes in weather.
- Confirm that the GapCap, TopCap is securely installed.

By following these detailed steps, you can effectively install a GapCap, TopCap onto your new deck to cover unwanted gaps and ensure a neat finish.